

RemotePoint®

# Emerald Navigator SE

## User's Manual



Special Edition  
Green Laser Pointer

VP4155

Rev. A

## Laser Safety Warning

CAUTION: Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure. The laser is activated by pressing the laser button identified in the user guide.

**Do not stare into the laser beam, or shine the laser at others.**

Do not allow minors to use the laser unsupervised.

Avoid pointing the laser pointer at any reflective surface.

Do not disassemble the device, it has no serviceable parts.

Do not immerse in any liquid or expose to heat or moisture.


Use only within the designed operating temperature range of 0-40 degrees C.

### Laser Specifications:


The laser used in the VP4155 complies as Class 2 laser product with: IEC/EN 60825-1: 2007, and CFR Title 21 1040.10 and 1040.11, except for deviations pursuant to Laser Notice No. 50, dated June 24, 2007. A complete Declaration of Conformity can be found at [www.SMK-Link.com](http://www.SMK-Link.com).

## Getting Started

1. Install batteries in the battery compartment.



2. With the computer turned on, plug the receiver into a free USB port. (If the computer displays a "Found New Hardware" dialog box, click Next until the driver is installed.)



3. Initialize the Emerald Navigator SE by pressing the *HIDE/REVEAL* button within 10 minutes of connecting the receiver.



## Changing the Language Key Code

In certain languages a different key code may be needed to blank the screen during a presentation. Three key codes are provided for the various presentation programs.

To change between the codes:

- Insert the receiver into a USB port.
- Use a paper clip to press and release the recessed button on the receiver.
- The LED on the receiver will turn orange.
- Start a slide show and test the Blank screen feature.



## Setting Up Emerald Navigator SE

Your presentation remote comes set up from the factory. In most situations no adjustments are needed; however, if you have many remotes or another device which is causing interference, complete these steps to avoid interference.

## Training the Receiver

1. To train the receiver to accept the digital code from the remote, remove the USB receiver from the USB port and reconnect it after a few seconds.
2. Press and hold the *NEXT SLIDE* button for 10 seconds until the green light on the remote turns back on. The LED on the receiver should turn from flashing green to solid green then back to flashing green.

## Changing Channels

1. Remove the battery from the remote.
2. Replace the battery and hold down the *PREVIOUS SLIDE* button for 10 seconds.
3. The LED on the remote will blink the number of the current channel. Each time you press the Previous button it increases the channel by one.
4. Once you are on channel 4, increasing the channel will move it back to channel 1.
5. The LED will blink rapidly the number of the current channel.
6. Press the *PREVIOUS SLIDE* button to confirm the channel.
7. Train the receiver again using the steps listed in "Training the Receiver."

# Emerald Navigator SE Controls

Activate Laser

Previous Slide

Next Slide

Hide/Reveal



## Emerald Navigator SE

(Model 4155)

Laser Specification:

Max output power: < 1mW.

Emitted wavelength: 515nm

The Class 2 laser beam is emitted from the front of the device, indicated by the aperture warning label.



## Warranty

SMK-Link Electronics Corporation (SMK-Link) warrants to the original end-user purchaser of the Product (“you”) that the Product, excluding batteries, will be free from defects in materials and workmanship under normal use and service for one-year from date of purchase. If the Product becomes defective in materials or workmanship during the warranty period, SMK-Link will, at its option, either repair or replace it. The replacement unit may be a more current or upgraded model if the originally purchased model is not available. Any Product repaired or replaced under the terms of the warranty is covered for the remainder of the original warranty period or ninety (90) days from the date of return shipment, whichever is longer.

This warranty does not cover Products which have been subjected to misuse, accident, physical damage, improper installation, abnormal operation or handling, neglect, inundation or fire or when Product regulatory label has been removed, altered or rendered illegible; nor does it cover accessory or consumable items. SMK-Link shall not be liable for any indirect special, incidental, or consequential damages. SMK-Link’s total liability for damages for any cause related to, or arising out of, the use or inability to use the Product shall not exceed the original price paid for the Product even if SMK-Link has been informed of such possibility.

If your Product requires service under warranty, you must first contact SMK-Link product support to receive an RMA number. Shipping of defective units back to SMK-Link is at your expense. The contact information can be found on the SMK-Link website: [www.smklink.com](http://www.smklink.com). The warranty does not affect your statutory rights and you may have other rights which vary from state to state and country to country. This warranty is understood to be the complete and exclusive agreement between the parties, superseding all prior agreements, oral or written, and all other communications between the parties relating to the matter of this warranty. The above warranty does not apply to Products sold in Australia. Products sold in Australia by an authorized reseller will contain an Australia specific warranty statement.

## FCC Certification

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

In order to maintain compliance with FCC regulations, shielded cables must be used with this equipment. Operation with non-approved equipment or unshielded cables is likely to result in interference to radio and TV reception. The user is cautioned that changes and modifications made to the equipment without the approval of manufacturer could void the user's authority to operate this equipment.

# CE Declaration of Conformity

Manufacturer:

SMK-Link Electronics Corporation

3601-B Calle Tecate

Camarillo, CA 93012

Hereby, SMK-Link declares that the VP4155 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

## **EMC/EMI/Safety Standards**

EN 300 440-2 V1.1.1 (2001-09)

EN 301 489-1 V1.4.1 (2002-08)

EN 301 489-3 V1.4.1 (2002-08)

EN 60825-1 (1994, A11:1996, A2:2001)

## Canada, Industry Canada (IC) Notices

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radioexempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.



## Thank You

Congratulations on your purchase of the RemotePoint Emerald Navigator SE. We thank you for choosing SMK-Link Electronics to meet your wireless needs and look forward to serving you in the future. To learn about new SMK-Link products as they become available, and to ensure the best possible customer support, please register your product online at [www.smklink.com/register](http://www.smklink.com/register).

## Support

### **SMK-Link Electronics Corporation**

3601-B Calle Tecate  
Camarillo, CA 93012

TEL: **(888) 696-3500** | (805) 987-6662

FAX: (805) 987-6665

Email: **[pcsupport@smkusa.com](mailto:pcsupport@smkusa.com)**

[www.smklink.com](http://www.smklink.com)

©2016 SMK-Link Electronics Inc. SMK-Link, the SMK-Link logo, and RemotePoint are registered trademarks of SMK-Link Electronics, Inc. Windows, and PowerPoint are registered trademarks of Microsoft Corporation in the United States and other countries. Apple, OS X and Keynote are registered trademarks of Apple Inc. All other registrations and trademarks are properties of their respective owners.





The logo for SXIK Link features a stylized orange satellite dish icon above the text "SXIK Link". The text "SXIK" is in a light blue, sans-serif font, and "Link" is in a darker blue, sans-serif font. The background is dark grey with a large, curved, metallic-looking shape that resembles a satellite dish or a lens.

SXIK Link